



## Configuration NoMix (COP)

Description of Components	Part No.	No. of Compartments				
		3	4	5	6	7
Central unit and display for NoMix	NM2MAINDISP2	1	1	1	1	1
Wet-leg sensor interface for NoMix and MultiSeal-SPD, up to 6 compartments	NM2WET2	1	1	1	1	2
Input/output interface for NoMix and MultiLevel, up to 6 compartments	NM2IO	1	1	1	1	2
TAG-Scan-interface for NoMix, 14 channels	NM2TAG	1	1	1	1	2
Cable for NoMix, MultiSeal and MultiLevel, L = 12.5 m	NM2KABEL	1	1	1	1	1
Main pressure switch for air supply for NoMix and MultiSeal	NM2DSS	1	1	1	1	1
Wet-leg sensor for NoMix and MultiSeal, with mounting accessories, weld-in nozzle aluminium	NS-2F	3	4	5	6	7
Solenoid valve 3/2-way, single, 12 V DC, EEx m II T5, cable length 3 m, with emergency manual override	QMV1D	3	4	5	6	7
Solenoid valve 3/2-way, single, 12 V DC, EEx m II T5, cable length 3 m, with emergency manual override	QMVBS	1	1	1	1	1
Cable LIY11Y, coil with 25 meter	ASS-GS-K25M	1	1	1	1	1
Flange isolation DN100, glass fibre reinforced	ASS-GW-I100G	4	5	6	7	8
Resistor for flange connection (NoMix)	ASS-GW-ESA	4	5	6	7	8

### Options:

Weld-in boss (aluminum) for wetleg sensor NS-2x	23647 A	6	8	10	12	14
Weld-in boss (steel) for wetleg sensor NS-2x	252154	6	8	10	12	14
Amplifier for multiple overfill prevention for NoMix	NM2ASEM	1	1	1	1	1
Cable 15 m, with plug for thermistor overfill prevention	ASS-GW-GWGS	2	2	2	2	2
Man machine interface (Display) for NoMix and MultiSeal SPD	NM2DISPLAY	1	1	1	1	1
Communication-Interface EMIS2 for MultiFlow, NoMix, MultiSeal and MultiLevel	EMIS2	1	1	1	1	1
API coupling, lever operated 4", with sight glass and locking bolt	VKV1MB	3	4	5	6	7