

**01—Air Eliminators**

P0100.04	Eliminator, Air, Dual Electric, DE-1 and DE-2
P0101.04	Eliminator, Air, R.B. Head
P0102.03	Eliminator, Air, R.B. Head, Petro-gard
P0103.04	Eliminator, Air, U.B. Head
P0105.01	Eliminator, Air, Truck, T2A-1
P0106.02	Eliminator, Air, Truck, T3A-1
P0107.01	Eliminator, Air, Truck, T-4A
P0108.01	Eliminator, Air, Truck, TEB-10
P0109.01	Eliminator, Air, Truck, TEB-15
P0110.01	Eliminator, Air, Truck, TEB-30
P0111.02	Eliminator, Air, Truck, ME-50
P0113.00	Eliminator, Air, Three Float, DE-3

**02—Compensators-Mechanical**

P0201.00	Adapter, Offset Dual Head
P0202.03	ATG
P0203.02	Calibrator, Dummy
P0204.02	Calibrator, G
P0205.02	Calibrator, Models AM-1, AM-3, AT-1, AT-2, and AT-3
P0206.02	Calibrator, Models AM-5, AT-5, and ATS-5
P0207.01	Compensator, Automatic, Temperature, ATC
P0208.03	Compensator, Parts Ordering Guide
P0209.03	DATC
P0210.05	LEATC, Enhanced I

**03—Counters-Mechanical**

P0301.02	Counter, Barreling, 500 Series
P0302.07	Counter, Non-Reset, 200A, and SM-200A (Stack Monitor)
P0303.02	Counter, Push-Button Set Stop, 300 Series

**04—Instrumentation-Electronic**

P0401.03	AccuLoad III-S
P0401.23	AccuLoad III-Q
P0401.42	AccuLoad III-SA
P0401.63	AccuLoad I to III Upgrade
P0402.52	AccuLoad II
P0404.03	Load Printer
P0406.02	SyberTrol
P0407.00	TCP-LU LACTMaster Flow Computer
P0407.50	TCP-NOC Net Oil Computer
P0411.03	Totalizer, Meter Mounted, Model MMT-25
P0415.02	Totalizer, CPC-22
P0418.02	AccuLoad II to III Upgrade
P0419.02	microLoad.net
P0420.00	Proximity Card Reader
P0421.00	AccuLoad III-N4
P0422.00	microFlow.net Liquid
P0423.00	microFlow.net Gas

**05—Meters****Industrial****DuraFlow**

P0501.04	Meter, DuraFlow, Model GMD-10
----------	-------------------------------

**Oval Gear**

P0513.02	Meter, Oval Gear, 3/4 Inch
P0514.03	Meter, Oval Gear, 1 Inch
P0515.03	Meter, Oval Gear, 1-1/2 Inch
P0516.02	Meter, Oval Gear, 2 Inch

**Prime Meter**

P0518.05	Meter, PRIME4
----------	---------------

**Rotary Vane**

P0532.03	Meter, PD Model I-75
P0533.01	Meter, PD Model I-150

**PD Series****Standard Meters**

P0538.08	Meter, PD Model SC-13
P0539.04	Meter, PD Model SD3-S1
P0540.02	Meter, PD Model SD or ASD-3, 3R, 3V, or 3VR-NF
P0541.03	Meter, PD Model SD, ASD, SF, or ASF-4, 4R, 4V, or 4VR-NF
P0542.03	Meter, PD Model SF, SG, ASF, or ASG-6, 6V, 6R, or 6VR-NF
P0543.05	Meter, PD Model SD-30
P0544.07	Meter, PD Series C2-S1, S3, S5, S6, S7
P0545.07	Meter, PD Series E3-A1, S1, S1C, A3, S3, S3C, S5, S5C, S6, S7
P0545.52	Meter, PD Series E4-S1
P0546.08	Meter, PD Series F4-A1, S1, A3, S3, S5, S6, S7
P0547.03	Meter, PD Series F4-V1, VA1
P0548.12	Meter, PD Series G6-A1, S1, A3, S3, S5, S6, S7
P0549.04	Meter, PD Series G6-V1
P0550.07	Meter, PD Series H8-S1, S3, S5, S6, S7
P0550.50	Meter, PD Series H8-S3 - Flat Plate Cover
P0551.04	Meter, PD Series JA10-S1, S3, S5, S6, S7
P0552.07	Meter, PD Series JB10-S1, S3, S5, S6, S7
P0553.04	Meter, PD Series K12-S1, S3, S5, S6, S7
P0554.04	Meter, PD Series M16-S1, S3, S5, S6
*P0554.53	Meter, PD Series M16-S3, S5, S6
P0568.00	Meter, PD Series VSC-13

\*For meters which began shipping in 1993 to current

## Truck

P0565.09 Meter, PD Model T-11, T-11NF  
P0566.04 Meter, PD Model T-20, T-20NF  
P0567.05 Meter, PD Model T-40

## Turbine Meters

### Guardzman (G) Series

P0573.08 Meter, Turbine, 1-1/2 Inch, Guardsman (G) Series  
P0574.11 Meter, Turbine, 2 Inch, Guardsman (G) Series  
P0575.10 Meter, Turbine, 3 Inch, Guardsman (G) Series  
P0576.09 Meter, Turbine, 3 Inch Low Flow, Guardsman (G) Series  
P0577.11 Meter, Turbine, 4 Inch, Guardsman (G) Series

### Guardzman L (GL) Series

P0578.04 Meter, Turbine, 1-1/2 Inch, Guardsman L (GL) Series  
P0579.04 Meter, Turbine, 2 Inch, Guardsman L (GL) Series  
P0580.07 Meter, Turbine, 3 Inch, Guardsman LB Series  
P0580.58 Meter, Turbine, 3 Inch, Guardsman LJ Series  
P0581.04 Meter, Turbine, 4 Inch, Guardsman LB Series  
P0581.57 Meter, Turbine, 4 Inch Guardsman LJ Series  
P0582.04 Meter, Turbine, 3 Inch, Guardsman LSJ Series  
P0583.04 Meter, Turbine, 4 Inch Guardsman LSJ Series

### Sentry Series

P0586.07 Meter, Turbine, 4 Inch, Sentry Series  
P0587.06 Meter, Turbine, 6 Inch Low Flow, Sentry Series  
P0588.06 Meter, Turbine, 6 Inch, Sentry Series  
P0589.07 Meter, Turbine, 8 Inch, Sentry Series  
P0590.07 Meter, Turbine, 10 Inch, Sentry Series  
P0591.06 Meter, Turbine, 12 Inch, Sentry Series  
P0592.04 Meter, Turbine, 16 Inch, Sentry Series  
P0593.04 Meter, Turbine, 18 Inch, Sentry Series  
P0594.03 Meter, Turbine, 20 Inch, Sentry Series

### Multi Viscosity Series

P0595.01 Meter, Turbine, 3 Inch, Multi-Viscosity  
P0595.52 Meter, Turbine, 4 Inch, Multi-Viscosity  
P0596.03 Meter, Turbine, 6 Inch, Multi-Viscosity  
P0596.52 Meter, Turbine, 8 Inch, Multi-Viscosity  
P0597.02 Meter, Turbine, 10 Inch, Multi-Viscosity  
P0597.52 Meter, Turbine, 12 Inch, Multi-Viscosity  
P0598.02 Meter, Turbine, 16 Inch, Multi-Viscosity

## 06—Meter Accessories

P0601.01 Adapter, Angle  
P0602.01 Adapters, Meter Dome  
P0602.51 Bolt Application Guide  
P0603.03 Extensions, Rigid and Ventilated  
P0603.51 Gear Clusters  
P0604.00 Indicator, Mechanical Flow Rate  
P0605.05 Packing Glands

P0606.03 Right Angle Drive  
P0607.01 Shifter, Dual Counter  
P0608.03 Spiders and Bushings

## 08—Strainers

P0800.00 Strainers, Angle, 44-C3, 4 Inch  
P0801.03 Strainers, E-Series, 2 Inch  
P0802.03 Strainers, E-Series, 3 Inch  
P0803.03 Strainers, E-Series, 4 Inch  
P0804.03 Strainers, E-Series, 6 Inch  
P0805.02 Strainers, E-Series, 8 Inch  
P0806.01 Strainers, PD Meters, 6 Inch Through 16 Inch  
P0807.01 Strainers, Turbine Meters, 4 Inch Through 20 Inch  
P0808.01 Strainers, Type Y  
P0809.01 In-Line Strainer Series

## 09—Transmitters

P0903.04 Transmitter, Model PEX and PEX-P  
P0904.53 Transmitter, Model PPS  
P0905.02 Transmitter, Type D  
P0906.03 Transmitter, Type E  
P0907.03 Transmitter, Model UPT

## 10—Valves

P1001.01 Accelerator Control, Model 21A  
P1002.00 Amplifier, Model 29  
P1003.04 Controller, Valve, Model SS1  
P1004.01 Check Feature Kit, Model 80B, 84B  
P1006.02 Check Pilot, Diaphragm Model 12  
P1007.01 Excess Flow Control, Models 44A, 45A  
P1008.04 Faucet, Models BP2S, BPG2  
P1009.04 Faucet, Models MP2S, MPG2  
P1010.05 Faucet, Models SP2S, SPG2  
P1011.02 Faucet, Models MPG3, SPG3  
P1012.00 Faucet, Models MG4, SG4  
P1013.00 Faucet, Model XR-2  
P1014.02 Fusible, Link Pilot, Model 190A  
P1015.00 Liquid Level Controls, Models 110, 111  
P1016.00 Liquid Level Controls, Models 112, 113  
P1017.01 Liquid Level Float Control, 2-Way, Model 100  
P1018.01 Liquid Level Float Control, 3-Way, Models 101, 102  
P1019.07 Position Indicator, Models 04A, 04B  
P1019.52 Position Indicator, Model 05R  
P1020.04 Pressure Control, Models 60A, 63A, 64A  
P1021.03 Pressure Reducing Control, Models 50A and 50B  
P1022.03 Pressure Sensing Pilot, Models 23, 23A, 23PG, 23BP, 23DP  
P1023.03 Rate of Flow Control, Models 40A, 42A  
P1024.01 Set-Stop Pilot, 2 Stage, Model 196  
P1025.00 Solenoids, Control, Models 30, 30A, 30B, and 31  
P1030.01 Strainer, Model 09Y  
P1031.00 Strainer, Self Cleaning, Model 09SC  
P1032.01 Thermal Relief Control Valve, Model 07

P1032.50	Timer, Low Flow Start, Models 15A and 15AX	P1052.03	Valve, Hydraulic Set Stop, Model 296, 3 Inch
P1033.00	Valve, Automatic Drain, Models 130, 131	P1053.02	Valve, Hydraulic Set Stop, Model 296, 4 Inch
P1033.50	Valve, Ball, Model 03A	P1054.01	Valve, Hydraulic Set Stop, Model 296, 6 Inch
P1034.08	Valve, Control, Model 210, 2 Inch	P1055.02	Valve, Hydraulic Set Stop, Model 299, 3 Inch
P1035.05	Valve, Control, Model 210, 3 Inch	P1056.01	Valve, Hydraulic Set Stop, Model 299, 4 Inch
P1036.10	Valve, Control, Model 210, 4 Inch	P1057.02	Valve, Hydraulic Set Stop, Model 299, 6 Inch
P1037.08	Valve, Control, Model 210, 6 Inch	P1058.01	Valve, Hydraulic Set Stop, Model 299, 8 Inch
P1038.01	Valve, Control, Model 210, 8 Inch	P1061.01	Valve, Mechanical Set Stop, 2 Inch
P1039.07	Valve, Hydraulic, 200 Series, 2 Inch	P1062.00	Valve, Mechanical Set Stop, 3 Inch
P1040.05	Valve, Hydraulic, 200 Series, 3 Inch	P1063.00	Valve, Mechanical Set Stop, 4 Inch
P1041.08	Valve, Hydraulic, 200 Series, 4 Inch	P1064.00	Valve, Mechanical Set Stop, 6 Inch
P1042.02	Valve, Hydraulic, 200 Series, 6 Inch	P1064.52	Valve, Needle, Model 13
P1043.02	Valve, Hydraulic, 200 Series, 8 Inch	P1065.02	Valve, Pneumatic Wafer Sphere, Model 215, 3 Inch
P1044.00	Valve, Hydraulic Piston, Model 200P, 8 Inch	P1066.02	Valve, Pneumatic Wafer Sphere, Model 215, 4 Inch
P1045.01	Valve, Hydraulic Piston, Model 200P, 10 Inch	P1067.01	Valve, Pneumatic Wafer Sphere, Model 215, 6 Inch
P1046.02	Valve, Hydraulic Piston, Model 200P, 12 Inch	P1068.01	Valve, Pneumatic Wafer Sphere, Model 215, 8 Inch
P1047.03	Valve, Hydraulic Power Chamber, Model 200PC, 3 Inch	P1071.04	Valve, Position Indicator, Model 02A
P1048.02	Valve, Hydraulic Power Chamber, Model 200PC, 4 Inch	P1076.01	Valve, Reduced Port, Model 210
P1049.02	Valve, Hydraulic Power Chamber, Model 200PC, 6 Inch		
P1050.01	Valve, Hydraulic Power Chamber, Model 200PC, 8 Inch		
P1050.10	Valve, Hydraulic Power Chamber, Model 200PC, 10 Inch		
P1051.03	Valve, Hydraulic Set Stop, Model 296, 2 Inch		

## 12—Miscellaneous

P1202.04	Lubricants, Sealants, Adhesives, Solvents, and Paint
P1205.03	Tools, Mechanical

## How to Read Your Smith Meter® Parts List

Smith Meter® uses an identification format in the description section of the parts list to enable the customer to determine the component parts/variations, if available, of a part being ordered.

All unit parts are listed at the left-hand margin of the description column.

All components or variations for a unit part are further indented to the right, just below the unit part.

Any further indentations to the right will represent variation of the above component or represent a component of the above unit component and/or the unit part.

**Example 1:** See Parts List Form No. P0550.XX, Items 135 through 138

Shaft and Cam Assembly .....	1	513066-001	(Unit Part)
Cam .....	1	512510-001	(Component of Unit Part)
Key, Locating Arm .....	1	513064-001	(Component of Unit Part)
Shaft.....	1	513061-001	(Component of Unit Part)

**Example 2:** See Parts List Form No. P0573.XX, Items 16 and 17

Rotor Assembly:			(Unit Part)
Standard	1	540885-001	(Variation of Unit Part)
Nickel Plated .....	1	540885-101	(Variation of Unit Part)
Bearing, Rotor .....	1	540296-204	(Component of Unit Part)